

OPENFIT AIR

User Guide

T511

APP

Stáhněte si aplikaci Shokz

Aplikace Shokz vám umožňuje přepínat režimy EQ, připojit se ke dvěma zařízením současně, přizpůsobit dotykové ovládání, upgradovat firmware a další. Stáhněte si aplikaci nyní pro jednoduchý a bezproblémový zvukový zážitek.

**Apple a logo Apple jsou ochranné známky společnosti Apple Inc., registrované v USA a dalších zemích. Google Play je ochranná známka společnosti Google LLC.*



Shokz



Návod

3 OBSAH BALENÍ

5 NOŠENÍ A POUŽÍVÁNÍ

6 Schéma sluchátka

7 Nabíjecí pouzdro

8 Párování

10 Nošení

12 DOTYKOVÉ OVLÁDÁNÍ

13 Ovládání hudby

14 Ovládání hovorů

15 Ovládání hlasitosti

16 Ovládání jednoho sluchátka

17 INDIKAČNÍ LED

18 LED indikátor nabíjecího pouzdra

20 POWER SOURCE

21 Zapnuto/Vypnuto/Pohotovostní režim

23 Nabíjení sluchátek

24 Nabíjení nabíjecího pouzdra

25 DALŠÍ FUNKCE

26 Vícebodové párování

28 Automatické připojení

29 Resetování

30 ÚDRŽBA

31 Čištění

32 IP hodnocení


33 POPRODEJNÍ SERVIS

34 Umístění sériového čísla


35 Záruka

OBSAH BALENÍ


OBSAH BALENÍ



OpenFit Air
True Wireless sluchátka *2




OpenFit Air
nabíjecí pouzdro *1



OpenFit Air
krabička *1



USB-C nabíjecí kabel
*1



Návod *1



Právní prohlášení *1




Záruční list *1

Výrobek nepoužívejte, pokud některá z výše uvedených položek chybí nebo je výrobek poškozen. Kontaktujte prosím svého prodejce nebo nás.
(Viz strana 33: Poprodejní servis – kontaktujte nás)


NOŠENÍ A POUŽÍVÁNÍ

Schéma sluchátka




*Dotykové tlačítko se nachází v oblasti sluchátka s logem Shokz..

Nabíjecí pouzdro



LED indikátor nabíjecího pouzdra

Párování




Při prvním použití:

Otevřete nabíjecí pouzdro a okamžitě přejdete do režimu BT párování, přičemž kontrolka bliká oranžově a zeleně.


Pro další párování:

1. Vložte obě sluchátka do nabíjecího pouzdra.
2. Současně stiskněte a podržte dotykovou oblast obou sluchátek dvěma prsty (jeden prst na sluchátko), dokud kontrolky nezačnou blikat oranžově a zeleně, což znamená, že sluchátka vstoupila do režimu BT párování.



3. Zapněte funkci Bluetooth a vyberte „OpenFit Air by Shokz“. Zařízení po dokončení zobrazí úspěšné spárování.

NOŠENÍ




1. Vyjměte sluchátko z pouzdra.
2. Umístěte jej nad ucho.





3. Opatrně otočte špunt dozadu, aby se háček omotal kolem vašeho ucha.
4. Jste připraveni vyrazit.


DOTYKOVÉ OVLÁDÁNÍ







OVLÁDÁNÍ HUDBY




L	 Přehrát/pozastavit hudbu ● ● Při přehrávání hudby dvakrát klepněte
R	 Přehrát další skladbu ● ● Při přehrávání hudby dvakrát klepněte





OVLÁDÁNÍ HOVORŮ



L or R		Přijmout hovor Dvakrát klepněte na kterékoli sluchátko	
		Ukončit hovor Dvakrát klepněte na kterékoli sluchátko	
		Odmítnout hovor Při příjmu hovoru dlouze stiskněte L nebo R	


OVLÁDÁNÍ HLASITOSTI



L	 Snížit hlasitost o jednu úroveň Během hudby nebo hovorů dlouze stiskněte po dobu 2 sekund 
R	 Zvýšit hlasitost o jednu úroveň Během hudby nebo hovorů dlouze stiskněte po dobu 2 sekund 

Plynulé ovládání hlasitosti: Během hudby nebo hovorů dlouze stiskněte odpovídající sluchátko, dokud nedosáhnete požadované hlasitosti

OVLÁDÁNÍ JEDNOHO SLUCHÁTKA




Obě sluchátka jsou navržena pro nezávislé použití, což umožňuje mono přehrávání hudby nebo hovory. Při samostatném použití si každé sluchátko zachová funkci příslušného tlačítka. Ovládání hudby naleznete na straně 13 a ovládání hovorů naleznete na straně 14.

INDIKÁTOR

LED

LED INDIKÁTOR NABÍJECÍHO POUZDRA



1. Když jsou sluchátka v nabíjecím pouzdře, indikátor zobrazuje úroveň nabití baterie sluchátek.

Vysoká úroveň nabití baterie	Při otevření zelené světlo po 5 sekundách zhasne
Nízká úroveň nabití baterie	Při otevření oranžové světlo po 5 sekundách zhasne

**Poznámka: Když jsou obě sluchátka vložena do nabíjecího pouzdra, indikátor zobrazuje úroveň nabití sluchátka s nižší úrovní baterie.*



2. Když nejsou sluchátka v nabíjecím pouzdře, indikátor zobrazuje úroveň nabití baterie nabíjecího pouzdra.

Nabíjecí pouzdro s vysokou úrovní nabití baterie	Zelené světlo zhasne po 5 sekundách po otevření nebo zavření pouzdra
Nabíjecí pouzdro s nízkou úrovní nabití baterie	Oranžové světlo zhasne po 5 sekundách po otevření nebo zavření pouzdra

3. Při připojení k externímu zdroji napájení.

Nabíjení	Indikátor svítí oranžově
Nabíjení dokončeno	Indikátor svítí zeleně


4. Ostatní

Párování	Indikátor bliká oranžově a zeleně
Obnovení továrních dat	Indikátor bliká oranžově po dobu 5 sekund

POWER SOURCE

Zapnuto/Vypnuto/ Pohotovostní režim


(On/Off/Standby)



1. Zapnuto(ON):

Když jsou sluchátka vložena do nabíjecího pouzdra, otevření pouzdra aktivuje kontrolku a zapnutí sluchátek.

**Poznámka: Zavření nabíjecího pouzdra po vyjmutí náušníků pomáhá šetřit životnost baterie a zabraňuje vnikání nečistot do pouzdra.*




2. Vypnuto(OFF):

Když zavřete nabíjecí pouzdro s oběma sluchátky uvnitř, automaticky se sluchátka vypnou.

3. Pohotovostní režim(Standby):

Když sluchátka nevložíte do nabíjecího pouzdra a zůstanou odpojená od zařízení Bluetooth po dobu 3 minut, přejdou do pohotovostního režimu, aby se prodloužila životnost baterie.

NABÍJENÍ SLUCHÁTEK



- Green light - High battery level
- Orange light - Low battery level


Place the earbuds into the charging case until they magnetically attach. Close the charging case once the indicator light is on.

*Note: The earbuds will reach full charge after approximately 60 minutes inside the charging case. Ensure that the charging case has sufficient battery level to charge the earbuds.

NABÍJENÍ NABÍJECÍHO POUZDRA



● Orange light on the charging case



Charging port

Connect the USB-A to USB-C charging cable to the charging case and plug it into a USB-A power supply or certified wall charger. A solid orange light on the charging case indicates that it is currently charging, while a solid green light indicates that the case is fully charged.

*Note:

- The charging case requires approximately 2 hours to reach full charge. It operates using the standard $5V\pm 5A$ USB voltage. We advise against using high-voltage power sources to charge the earbuds, as this may cause damage. Additionally, using third-party charging cables may result in longer charging times.
- Before charging, ensure that the charging port is dry and free of liquid residue like sweat. Use a soft, dry cloth to wipe away any moisture or residue from the charging port.


DALŠÍ FUNKCE

VÍCEBODOVÉ PÁROVÁNÍ

(MultiPoint Pairing)

*Please update the Shokz App to the latest version in the App Store. Follow the instructions to update the headphone firmware to the latest version. Ensure that Bluetooth is enabled on your pairing device.

1. Start by selecting “MultiPoint Pairing” in the Shokz App.




2. On the pop-up page, confirm to open the Multi-Point Pairing function.
3. Select "Connect To The Second Device" and follow the instructions to establish a connection with the second device.



4. Your headphones are now connected to two devices. You can manage their Bluetooth connections conveniently through the Shokz App.

Auto Connect



1. Once the earbuds are powered on, they'll automatically attempt to connect to the last paired device and emit a beep to indicate a successful connection.


2. While in use, the earbuds may disconnect from the paired device due to connection range limitations. If they come back within range within 3 minutes, they'll re-establish connection with the last paired device automatically, emitting a beep indicating successful reconnection.

3. Should the earbuds re-enter the connectable range after 3 minutes, double-tap either earbud to trigger automatic reconnection.

4. With multipoint pairing enabled, simply double-tap either earbud to reconnect to both devices.

*Please ensure that the paired devices are within the connection range (10m) and powered on. Also, make sure that your desired device has Bluetooth enabled.

Resetting



Resetting the earbuds will clear the list of paired devices and reset all settings.

1. Place both earbuds in the charging case.
2. Press and hold the touch area of both earbuds simultaneously with two fingers for 15 seconds. The indicator will flash orange for five seconds before turning off, indicating that the reset is complete. Next, the indicator will flash orange and green, indicating that the earbuds have entered pairing mode.

Maintenance

Cleaning

1. Earbuds:

- Use a soft, clean, dry cloth to wipe the earbuds.
- When cleaning the earphone mesh, gently brush away dirt and earwax with a dry cotton swab, then wipe with a soft cloth.

*Please note:

- Ensure the earbuds are powered off and disconnected from all devices before cleaning.
- Do not wash the earbuds with water or use ultrasonic cleaning.
- Prevent liquid from entering any openings of the earbuds.
- Do not use abrasive cleaners, high-concentration chemicals, alcohol, or acetone solvents, as they may cause damage, deformation, or discoloration.
- Avoid using sharp or abrasive objects.

2. Charging Case:

- Use a soft, clean, and dry cloth to wipe the exterior of the charging case.
- Use a clean, dry, soft brush to remove any debris from the charging interface.
- Gently wipe the charging contact surface inside the charging box using a clean and dry cotton swab.

*Please note:

- Ensure the charging case is powered off and disconnected from all devices before cleaning.
- Avoid using abrasive materials to clean the charging case.

IP rating

Tested under controlled laboratory conditions, the earbud components of this product are rated to withstand splashes at an IP54 level according to the IEC 60529 standard.




*Please note:

- The IP54 dust and water-resistant rating applies solely to the earbuds, not the charging case.
- The splash-proof feature is subject to degradation with regular use.
- Do not immerse the product in water, and avoid prolonged exposure to wet conditions. Do not use it during activities like swimming, water skiing, surfing, or other water sports.
- In the event of accidental water exposure, promptly wipe the product and accessories dry, then allow them to air dry in a cool, ventilated area. Do not use or charge until completely dry.

After-Sales Service

Serial Number Location



The product serial number is located on the barcode of the packaging and warranty card. Additionally, the charging case includes a serial number printed next to the charging port.

Warranty

Your headphones are covered by a warranty. Visit our website at <https://shokz.com/pages/warranty-return> for details of the limited warranty

SHOKZ